

Table of Contents

- 1 Description 2
- 2 Normal Operation 3
- 3 Standard Alerts 4
- 4 Operating Alarms 5
- 5 Top Menu 5
 - 5.1 LED Indicators Menu 6
 - 5.2 Enable/ Disable 7
- 6 Troubleshooting 10
 - 6.1 How to enter supervisor permission 10
 - 6.2 General Troubleshooting 14
 - 6.3 Alarms 16

1 Description

The Rigsmart System consists of a pair of Ram Position Sensors for each BOP Ram on the unit, a LED Ram Indicator module for each set of rams for use by the driller, and a Rigsmart panel to control and monitor the whole system. The Ram Position Sensors will be attached to each side of the ram, giving a definite indication of the position of both sides of the ram in case one side remains closed, or partially closed, while the other side is open. Each LED Ram Indicator module will correspond to a pair of ram sensors. The green light will indicate that both sides of the ram are open, while a red light will indicate that one or both sides of the ram are closed. The Rigsmart Panel will act as a ram indicator and will be able to turn off the LED Ram Indicators when they are not being used, to conserve battery life. If equipped, the Strobe Hub allows for large scale viewing of Ram Position Sensor status. If one Ram Position Sensor is detecting its BOP Ram closed the Strobe Light will switch to Red.

2 Normal Operation

In normal operation the panel will display the current BOP ram status with graphic as shown below.



If you press the SELECT key, you will be taken to the secondary operation screen. On this screen BOP ram pair status, LED status and average ram pair temperature will be displayed.

SYSTEM INFO		
RAM1 CLOSED 18.0°C LED OFF	RAM2 OPEN 18.0°C LED ON	RAM3 OPEN 18.0°C LED ON
EXIT ← LEDS ON/OFF SIG INFO SETUP		

After displaying the secondary operation screen for 8 seconds, the panel will automatically return to the main operation screen.

3 Standard Alerts

When the BOP rams are closed there is a screen flash and the pneumatic control will activate. There will be no audible alarm for this. The screens are shown below:

```
RAM 1
CLOSED
```

```
TOP MENU
LED INDICATORS ->SYSTEM
DIAGNOSTIC
OPERATIONS
RAM 1 CLOSED =23
EXIT
```

4 Operating Alarms

When the system encounters a problem an alarm message will flash on the panel screen, and the panel will beep. The message will flash and the beeping will continue until the detected problem is resolved.

5

```
RAM2 SIDE B
SYSTEM ALARM
```

```
TOP MENU
LED INDICATORS →SYSTEM
DIAGNOSTIC
OPERATIONS

RAM2 SIDE B SENSOR NOT FUNCTIONING =403
EXIT
```

Top Menu

Through normal system use the operator will occasionally need to access more advanced system menus to turn on and off different parts of the system. The system is designed to be modular so sets of Rams and LEDs can be added and taken away without major software changes. Also LEDs can be individually turned on or off, rather than all at once. All of these options can be accessed through the Top Menu.

```
TOP MENU
LED INDICATORS ->SYSTEM
                   DIAGNOSTIC
OPERATIONS

RAM2 SIDE B SENSOR NOT FUNCTIONING =403
EXIT
```

5.1 LED Indicators Menu

When the snubbing unit is not being used you may wish to turn off the LED Indicator modules to extend their battery life.

To turn on or off LEDs individually do the following:

- From the Top Menu, use the arrow keys to select LED INDICATORS and press SELECT.

```
TOP MENU
->LED INDICATORS SYSTEM
                   DIAGNOSTIC
OPERATIONS

RAM2 SIDE B SENSOR NOT FUNCTIONING =403
EXIT
```

- Use the arrow keys to select either all LEDS or the particular LED you wish to turn off and press SELECT. Using the arrow keys you will then be able to change the value from on to off. Once the correct state has been set press the ACCEPT key twice to save.

```
TOP MENU LED INDICATORS
-ALL LEDS ON
LED 1 ON
LED 2 OFF
LED 3 ON
EXIT BACK TOP MENU
```

5.2 Enable/ Disable

If a particular RAM pair or LED is not required at all, it can be disabled from the system. While this device is disabled no communication will occur between the transducer and the panel. The transducer will not operate and no alarms will be registered from the transducer. All other devices (that have not been disabled) will continue to work as normal.

To disable (or re-enable) a device, do the following:

- Enter the supervisor permission code, using the steps in the back of this manual
- From the TOP MENU use the arrow keys to go to Components and press SELECT

```
TOP MENU
LED INDICATORS SYSTEM
-COMPONENTS DIAGNOSTIC
OPERATIONS
RAM 1 = OPEN
EXIT
```

- Using the arrow keys highlight enable/disable and press SELECT
- Using the arrow keys highlight Manual and press SELECT
- Using the arrow keys highlight RAM&LEDS and press SELECT

```
TOP MENU>COMPONENTS
                                ->ENABLE/DISABLE
RAM 1 = OPEN
EXIT      BACK      TOP MENU
```

```
TOP MENU>COMPONENTS>ENABLE/DISABLE
                                AUTODisable
                                AUTODisable
                                ->MANUAL
```

```
TOP MENU>COMPONENTS>ENABLE/DISABLE
                                ->RAM&LEDS
RAM 1 = OPEN
EXIT      BACK      TOP MENU
```


- Using the arrow keys highlight the specific RAM or LED you wish to disable/enable and press SELECT
- Once selected, use the arrow keys to change the value to enable or disable and press ACCEPT twice to save.

TOP MENU>COMPONENTS>ENABLE/DISABLE			
→RAM 1A	ENABLE	LED 1	ENABLE
RAM 1B	ENABLE	LED 2	ENABLE
RAM 2A	DISABLE	LED 3	DISABLE
RAM 2B	DISABLE		
RAM 1 = OPEN			
EXIT	BACK	TOP MENU	

6 Troubleshooting

6.1 How to enter supervisor permission

- From the Main Operation Screen press SELECT.



- Use the up or down arrows on the panel to highlight the SETUP option and press SELECT.

If you do not press any keys for 8 seconds while viewing the Secondary Operation Screen, you will automatically be returned to the Main Operation Screen. Press SELECT again to return to the Secondary Operation Screen.

- You will now be in the TOP MENU. Use the Up and Down arrow keys to highlight SYSTEM and

```

TOP MENU
  -SYSTEM
    DIAGNOSTIC
    CALCULATIONS
RAM1 IS CLOSED = 23
EXIT
    
```

press SELECT

- Use the Up and Down arrow keys to highlight PERMISSION and press SELECT

```

TOP MENU>SYSTEM
  -ABOUT          PERMISSION
  LCD CONTRAST
RAM1 IS CLOSED = 23
EXIT    BACK    TOP MENU
    
```

```

TOP MENU>SYSTEM
  ABOUT          -PERMISSION
  LCD CONTRAST
RAM1 IS CLOSED = 23
EXIT    BACK    TOP MENU
    
```

- On the PERMISSION screen, with the word PERMISSION highlighted press SELECT and the

```

TOP MENU>SYSTEM>PERMISSION
Enter Permission code:
  -PERMISSION  127
RAM1 IS CLOSED = 23
EXIT    BACK    TOP MENU
    
```

```

TOP MENU>SYSTEM>PERMISSION
Enter Permission code:
  PERMISSION  127-
RAM1 IS CLOSED = 23
EXIT    BACK    TOP MENU
    
```

value next to it will also be highlighted.

- With the number highlighted, use the Up and Down arrows to change the value to the predetermined Supervisor Permission Code. This number is set with the rig manager at

```
TOP MENU>SYSTEM>PERMISSION
Press ACCEPT to save changes.
Press SELECT to discard changes.
      PERMISSION  123←
RAM1 IS CLOSED = 23
EXIT      BACK      TOP MENU
```

installation.

- When you have reached the desired number press the ACCEPT key once to accept the value,

```
TOP MENU>SYSTEM>PERMISSION
      SAVE - ARE YOU SURE?
      PERMISSION  123←
RAM1 IS CLOSED = 23
EXIT      BACK      TOP MENU
```

```
TOP MENU>SYSTEM>PERMISSION
      SAVING ...
      PERMISSION  123←
RAM1 IS CLOSED = 23
EXIT      BACK      TOP MENU
```

then press ACCEPT again to confirm and save your selection.

- If you enter the correct permission code, you will be returned to the TOP MENU. New options will be available in many menus.

```
TOP MENU
- COMPONENTS      SYSTEM
  HEIGHT RE-CAL  DIAGNOSTIC
  RAISE DERRICK  CALCULATIONS
  RUN CASING
RAM1 IS CLOSED   = 23
EXIT
```

If you enter an incorrect permission code, simply use the Up or Down arrows to highlight PERMISSION again and repeat the previous step to enter a different code.

If the permission code is unavailable please contact Rigsmart Service at 1-780-438-9475.

6.2 General Troubleshooting

Symptom	Cause	Solution
Panel Alarm Message		
Panel displays the message "RAM## SYSTEM ALARM" (where ## represents a number-letter combination referring to a ram)	<ul style="list-style-type: none"> The panel is not receiving a signal from the indicated Ram Position Sensor 	<ul style="list-style-type: none"> Reposition the antenna so that it is in direct line of sight with the Ram Position Sensors Check antenna connection Check for signs of physical damage
Panel displays the message "RAM## LOW BATTERY" (where ## represents a number letter combination referring to a ram)	<ul style="list-style-type: none"> The battery in the indicated Ram Position Sensor is low 	<ul style="list-style-type: none"> Contact the Rigsmart service department for a replacement battery.
Panel Display		
Panel incorrectly shows a ram as being open when it is closed, or vice versa	<ul style="list-style-type: none"> One side of the rams is locked or stuck in an unexpected position 	<ul style="list-style-type: none"> Verify this by physically checking the rams
	<ul style="list-style-type: none"> The panel antenna is not positioned where it can receive the best signal from the Ram Position Sensors: too far away, behind an obstruction 	<ul style="list-style-type: none"> Reposition the antenna so that it is in direct line of sight with the Ram Position Sensors
	<ul style="list-style-type: none"> The panel is receiving a conflicting signal from another sensor with the same ID 	<ul style="list-style-type: none"> If you have recently received a replacement component, ensure that the red and black wires have been cut on old component.

Symptom	Cause	Solution
LED Indicators		
The LED Indicator lights flash alternating red and green	<ul style="list-style-type: none"> The LED Indicator is not receiving a signal from the Ram Position Sensors 	<ul style="list-style-type: none"> Check the Rigsmart panel for displayed errors, then check the signal strength screen. Reposition the LED Indicator so that it is in direct line of sight with the Ram Position Sensors Check for signs of physical damage The battery in one of the Ram Position Sensors may be dead. Contact the Rigsmart service department.
The LED Indicator gives a double flash, or no longer flashes brightly	<ul style="list-style-type: none"> The LED Indicator battery is low 	<ul style="list-style-type: none"> Contact the Rigsmart service department for a replacement battery
The LED Indicator does not turn on or off when turned on or off by the panel	<ul style="list-style-type: none"> The LED Indicator cannot receive a signal from the panel 	<ul style="list-style-type: none"> Try turning the LED Indicators on and then off again, or vice versa Reposition the LED Indicator so that it is in direct line of sight with the panel antenna Check for signs of physical damage Contact the Rigsmart Service department for assistance with adjusting the transmission settings
	<ul style="list-style-type: none"> The LED Indicator has been disabled 	

6.3 Alarms

During the course of operation you may see various alarms displayed on the screen of the panel. You can look up the alarm in the following list to see what it means and any possible solutions.

Alarm Text	Number	Description
** BY-PASS ** XX SEC REMAIN	0	This message indicates that the By-pass button has been pressed on the front of the panel. Pressing the By-pass button will disable all alarms for 30 seconds. During the 30 seconds this message will flash on the main screen of the panel to indicate how much time is left.
RAM1 CLOSED	23	This message indicates that Both Ram 1A and Ram 1B are closed. This denotes that the pistons on both sides of the BOP are advanced. This message also indicates that the throttle is being diverted through the regulated path in the Throttle Override Pneumatics Box.
RAM1 SIDE A CLOSED	24	This message indicates that only Ram 1A is NOT detecting the BOP piston and Ram 1B IS detecting the BOP piston. This message also indicates that the throttle is being diverted through the regulated path in the Throttle Override Pneumatics Box. This can be due to only one of the pistons being advanced or the Ram Position Sensor being shifted away from the piston. Check the BOP for proper ram function.
RAM1 SIDE A SYSTEM ALARM	53	This alarm indicates that the panel is not receiving a signal from the 1A Ram Position Sensor. Either the sensor has stopped functioning due to a dead battery, damage, or failure, or the signal strength from the sensor is too low. Try repositioning the antenna for a more direct line-of-sight with the sensor.
RAM1 SIDE A LOW BATTERY	80	This alarm indicates that the battery in the 1A Ram Position Sensor is low. Please contact our service department for a replacement.
RAM2 CLOSED	173	This message indicates that Both Ram 2A and Ram 2B are closed. This denotes that the pistons on both sides of the BOP are advanced. This message also indicates that the throttle is being diverted through the regulated path in the Throttle Override Pneumatics Box. This is displayed only if BOP Ram set 1 is detected as open.
RAM1 SIDE B CLOSED	174	This message indicates that only Ram 1B is NOT detecting the BOP piston and Ram 1A IS detecting the BOP piston. This message also indicates that the throttle is being diverted through the regulated path in the Throttle Override Pneumatics Box. This can be due to only one of the pistons being advanced or the Ram Position Sensor being shifted away from the piston. Check the BOP for proper ram function.

Rigsmart Block Height and Depth System

Alarm Text	Number	Description
RAM1 SIDE B SYSTEM ALARM	203	This alarm indicates that the panel is not receiving a signal from the 1B Ram Position Sensor. Either the sensor has stopped functioning due to a dead battery, damage, or failure, or the signal strength from the sensor is too low. Try repositioning the antenna for a more direct line-of-sight with the sensor.
RAM1 SIDE B LOW BATTERY	230	This alarm indicates that the battery in the 1B Ram Position Sensor is low. Please contact our service department for a replacement.
RAM3 CLOSED	273	This message indicates that Both Ram 3A and Ram 3B are closed. This denotes that the pistons on both sides of the BOP are advanced. This message also indicates that the throttle is being diverted through the regulated path in the Throttle Override Pneumatics Box. This is displayed only if BOP Ram sets 1 and 2 are detected as open.
RAM2 SIDE A CLOSED	274	This message indicates that only Ram 2A is NOT detecting the BOP piston and Ram 2B IS detecting the BOP piston. This message also indicates that the throttle is being diverted through the regulated path in the Throttle Override Pneumatics Box. This can be due to only one of the pistons being advanced or the Ram Position Sensor being shifted away from the piston. Check the BOP for proper ram function. This is displayed only if BOP Ram set 1 is detected as open.
RAM2 SIDE A SYSTEM ALARM	303	This alarm indicates that the panel is not receiving a signal from the 2A Ram Position Sensor. Either the sensor has stopped functioning due to a dead battery, damage, or failure, or the signal strength from the sensor is too low. Try repositioning the antenna for a more direct line-of-sight with the sensor.
RAM2 SIDE A LOW BATTERY	330	This alarm indicates that the battery in the 2A Ram Position Sensor is low. Please contact our service department for a replacement.
RAM2 SIDE B CLOSED	374	This message indicates that only Ram 2B is NOT detecting the BOP piston and Ram 2A IS detecting the BOP piston. This message also indicates that the throttle is being diverted through the regulated path in the Throttle Override Pneumatics Box. This can be due to only one of the pistons being advanced or the Ram Position Sensor being shifted away from the piston. Check the BOP for proper ram function. This is displayed only if BOP Ram set 1 is detected as open.
RAM2 SIDE B SYSTEM ALARM	403	This alarm indicates that the panel is not receiving a signal from the 2B Ram Position Sensor. Either the sensor has stopped functioning due to a dead battery, damage, or failure, or the signal strength from the sensor is too low. Try repositioning the antenna for a more direct line-of-sight with the sensor.
RAM2 SIDE B LOW BATTERY	430	This alarm indicates that the battery in the 2B Ram Position Sensor is low. Please contact our service department for a replacement.

Rigsmart Block Height and Depth System

Alarm Text	Number	Description
RAM3 SIDE A CLOSED	474	This message indicates that only Ram 3A is NOT detecting the BOP piston and Ram 3B IS detecting the BOP piston. This message also indicates that the throttle is being diverted through the regulated path in the Throttle Override Pneumatics Box. This can be due to only one of the pistons being advanced or the Ram Position Sensor being shifted away from the piston. Check the BOP for proper ram function. This is displayed only if BOP Ram sets 1 and 2 are detected as open.
RAM3 SIDE A SYSTEM ALARM	503	This alarm indicates that the panel is not receiving a signal from the 3A Ram Position Sensor. Either the sensor has stopped functioning due to a dead battery, damage, or failure, or the signal strength from the sensor is too low. Try repositioning the antenna for a more direct line-of-sight with the sensor.
RAM3 SIDE A LOW BATTERY	530	This alarm indicates that the battery in the 3A Ram Position Sensor is low. Please contact our service department for a replacement.
RAM3 SIDE B CLOSED	574	This message indicates that only Ram 3B is NOT detecting the BOP piston and Ram 3A IS detecting the BOP piston. This message also indicates that the throttle is being diverted through the regulated path in the Throttle Override Pneumatics Box. This can be due to only one of the pistons being advanced or the Ram Position Sensor being shifted away from the piston. Check the BOP for proper ram function. This is displayed only if BOP Ram sets 1 and 2 are detected as open.
RAM3 SIDE B SYSTEM ALARM	603	This alarm indicates that the panel is not receiving a signal from the 3B Ram Position Sensor. Either the sensor has stopped functioning due to a dead battery, damage, or failure, or the signal strength from the sensor is too low. Try repositioning the antenna for a more direct line-of-sight with the sensor.
RAM3 SIDE B LOW BATTERY	630	This alarm indicates that the battery in the 3B Ram Position Sensor is low. Please contact our service department for a replacement.

Rigsmart Systems Inc. www.rigsmart.com (780) 438-9475